

**AROMA**<sup>®</sup>  
PROFESSIONAL



# instruction manual

ARC-5200SB/ARC-5200SG

Rice & Grain Multicooker

*Questions or concerns about your Aroma product?*

[www.AromaCo.com/Support](http://www.AromaCo.com/Support)

1-800-276-6286

DISCOVER  
more of our  
products!



Digital Rice & Grain Multicookers



Rice & Grain Cookers



Electric Kettles



Indoor Grills



...and More!

# AROMA®

To Enhance and Enrich Lives.

Here at Aroma we strive to make a difference—to design and distribute products that enhance and enrich people's lives.

Aroma offers an array of exceptional products to make cooking simple and satisfying. Discover other countertop appliances and cookware from our current product lineup to complement your kitchen.

## REGISTER YOUR PRODUCT



SCAN TO REGISTER  
[AromaCo.com/registration](https://www.AromaCo.com/registration)

Registration is quick and easy.

- Be notified of:
- new product releases
  - new test kitchen recipes
  - sales and promotions
  - ...and more!



[/AromaHousewares](https://www.instagram.com/AromaHousewares)



## IMPORTANT SAFEGUARDS

Basic safety precautions should always be followed when using electrical appliances, including the following:

1. **Important: Read all instructions carefully before first use.**
2. Do not touch hot surfaces. Use the handles or knobs.
3. Use only on a level, dry and heat-resistant surface.
4. To protect against fire, electrical shock and injury to persons, do not immerse the power cord, plug or appliance in water or any other liquid. See instructions for cleaning.
5. Close supervision is necessary when the appliance is used by or near children.
6. Unplug from the wall outlet when not in use and before cleaning. Allow the unit to completely cool before putting on or removing parts and before cleaning the appliance.
7. Do not operate any appliance with a damaged power cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact Aroma® customer service for examination, repair or adjustment.
8. The use of accessory attachments not recommended by Aroma® Housewares may result in fire, electrical shock or injury.
9. Do not use outdoors.
10. Do not let cord touch hot surfaces or hang over the edge of a counter or table.
11. Do not place on or near a hot gas or electric burner or in a heated oven.
12. Do not use the appliance for other than its intended use.
13. Extreme caution must be used when moving the appliance containing rice, hot oil or other liquids.
14. Do not touch, cover or obstruct the steam vent on the top of the appliance as it is extremely hot and may cause scalding.
15. Use only with a 120V AC power outlet.
16. Always unplug from the plug gripping area. Never pull on the cord.
17. The appliance should be operated on a separate electrical circuit from other operating appliances. If the electrical circuit is overloaded with other appliances, the appliance may not operate properly.
18. Always ensure the exterior of the inner pot is completely dry prior to use. If the inner pot is returned to the appliance when wet, it may damage or cause the product to malfunction.
19. Use extreme caution when opening the lid during or after cooking. Hot steam will escape and may cause scalding.
20. Food should not be left in the inner pot with the **Keep Warm** function on for more than 12 hours.
21. To turn the appliance off, press the (⏻) button then safely remove the plug from the wall outlet.
22. To reduce the risk of electrical shock, cook only in the removable inner pot provided.
23. Do not wrap or tie the power cord around the appliance.
24. **CAUTION:** Intended for countertop use only.
25. **WARNING:** Spilled food can cause serious burns. Keep appliance and cord away from children. Never drape cord over edge of counter, never use outlet below counter, and never use with an extension cord.
26. To prevent damage or deformation, do not use the inner pot on a stovetop or burner.
27. **CAUTION:** Do not use for deep frying.
28. Do not immerse in water.
29. To avoid spills and burns, do not carry rice cooker by the lid handle.



Published By:  
Aroma Housewares Co. | 6469 Flanders Drive, San Diego, CA 92121, U.S.A.  
1-800-276-6286 | [www.AromaCo.com](https://www.AromaCo.com)

©2023 Aroma Housewares Company | All rights reserved.


## SAVE THESE INSTRUCTIONS



# IMPORTANT SAFEGUARDS

## Short Cord Instructions

A short power-supply cord is provided to reduce the risks resulting from it being grabbed by children, and becoming entangled in or tripping over a longer cord.



### WARNING

Spilled food can cause serious burns.  
Keep appliance & cord away from children.

**NEVER**

- Drape cord over edge of counter.
- Use outlet below counter.
- Use extension cord.

## Polarized Plug


This appliance has a polarized plug (one blade is wider than the other); follow the instructions below:

To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.

# THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY.

## Parts Identification



## Digital Controls



Powers the cooker on and off or cancels a current function.



Allows you to adjust the time for **Steam**, **Delay Timer**, **Slow Cook**, **Eggs** and **Soup**.

### White Rice

Cooks fluffy, delicious rice automatically.

### Brown Rice

Ideal for cooking brown rice to perfection.

### Quick Rice

A great time-saving option for rice in a pinch.

### Multigrain

Cooks a variety of grains from quinoa to barley and couscous with ease.

### Oatmeal

Prepares a quick and healthy breakfast with no need to stir or monitor.

### Steam

Easily steams healthy sides and main courses using the included steam tray.

### Soup

Simmers your favorite hot and hearty soups with an adjustable cook time of 2 to 8 hours.

### Sauté-then-Simmer®

Sautés foods on high heat then automatically switches to simmer mode once liquid is added. Great for pilaf, Spanish rice, chili, stir-fries and much more!

### Slow Cook

Prepare homemade roasts, stews and other slow-cooked favorites with an adjustable cook time of 2 to 10 hours.

### Risotto

Prepares rich and creamy one-pot risottos automatically.

### Cake

Easily bakes cakes and other sweet batter-based treats.

### Eggs

Sets the cook time from 6 to 14 minutes to prepare soft or hard boiled eggs.

### Reheat

Easily warms up leftovers.

### Delay Timer

Allows for food to be ready right when it's needed with preparation up to 15 hours in advance.

### Keep Warm

Manually sets the cooker to **Keep Warm** mode, perfect for keeping foods at ready-to-serve temperatures.

## BEFORE FIRST USE

1. Read all instructions and important safeguards.
2. Remove all packaging materials and check that all items have been received in good condition.
3. Tear up all plastic bags and dispose of them properly as they can pose a risk to children.
4. Remove the nonstick inner pot from the cooker and clean with warm, soapy water.
5. Wash all accessories in warm, soapy water.
6. Wipe the cooker's body clean with a damp cloth.
7. Dry all parts thoroughly then assemble for use.  
.....

## TO CLEAN

1. Remove the inner pot when the cooker has completely cooled.
2. Hand wash the inner pot and all accessories using warm, soapy water or place on the top rack of the dishwasher.
3. Remove the condensation collector and hand wash using warm, soapy water.
4. Wipe the cooker's body clean with a damp cloth.
5. Thoroughly dry the cooker's body and all accessories. Reassemble for next use.  
.....

## TROUBLESHOOTING

### **Rice is too dry/hard after cooking.**

- Depending on how dry your rice is, add ½ to 1 cup of water and stir thoroughly. Close the lid and select the **White Rice** function once more. When the cooker switches to **Keep Warm**, open the lid and stir the rice to check the consistency. Repeat as necessary until rice is soft and moist.

### **Rice is too moist/soggy after cooking.**

- Use the serving spatula to stir the rice to redistribute the bottom (moist) part of the rice as well as release excess moisture. Close the lid and allow the cooker to remain on **Keep Warm** for 10-30 minutes as needed, opening the lid and stirring periodically to release excess moisture.  
.....

6.



## Caution:

Do not use harsh abrasive cleaners, scouring pads or products that are not considered safe to use on nonstick coatings.

We recommend hand washing the inner pot with warm, soapy water to lengthen its lifespan and avoid damage over time. If washing in a dishwasher, a slight discoloration to the inner pot may occur. This is cosmetic and will not negatively affect performance.

Before placing the inner pot into the cooker, check that the inner pot is dry and free of debris. Adding the inner pot when wet may damage the cooker.

## Note:

- To remove the condensation collector, squeeze both sides and pull out towards you.
- Any other servicing should be performed by Aroma® Housewares.
- Not satisfied with your Aroma® purchase? Our product experts can help! **Before returning, please contact Customer Service at 1-800-276-6286** for product support, helpful tips and more!

If you misplace the measuring cup, a ¾ standard U.S. cup is an exact replacement.



## Error Code Chart

If an error shows on the digital display, the following chart will help explain the next course of action.

Display Code	Meaning	Action
E1	Bottom sensor circuit	Contact Aroma Customer Service at 1-800-276-6286.
E2	Bottom sensor short circuit	Allow to cool for 5 to 10 minutes then restart. If problem persists, contact Aroma Customer Service at 1-800-276-6286.
E5	Top sensor open circuit	Contact Aroma Customer Service at 1-800-276-6286.
E6	Top sensor short circuit	Allow to cool for 5 to 10 minutes then restart. If problem persists, contact Aroma Customer Service at 1-800-276-6286.

## RICE & GRAINS

1. Using the provided rice measuring cup, add rice or grain to the inner pot.
2. Rinse for 10 seconds and drain the water. Repeat this process at least 2 times, or until the water runs clear.
3. For white or brown rice, fill with water to the line that matches the number of cups of rice being cooked. For other grains, see "Grain & Water Measurement Table" on page 11.
4. Place the inner pot into the cooker and close the lid securely.
5. Plug the power cord into an available 120V AC wall outlet.
6. Press (⏻) to turn the cooker on.
7. Press **White Rice**, **Brown Rice** or **Multigrain** depending on the type of grain being cooked.
8. The cooking indicator light will illuminate and the digital display will show a chasing pattern as the cooker begins heating.
9. The digital display will count down the final 10 minutes of cook time.
10. Once the cycle has completed, the cooker will beep and automatically switch to **Keep Warm**.
11. For best results, stir the grain with the serving spatula to distribute any remaining moisture.
12. When finished, turn the cooker off by pressing (⏻) twice and unplug the power cord.  
.....



## Caution:

Before placing the inner pot into the cooker, check that it is dry and free of debris. Adding the inner pot when wet may damage the cooker.

## Note:

- Because rice varieties may vary in their make-up, results may differ.
- Food should not be left in the cooker on **Keep Warm** for more than 12 hours.
- For best results, we recommend rinsing rice and grains in a bowl of water before cooking. Avoid using a strainer or colander, which may not be as effective in removing excess starch and may affect the final texture.

## Helpful Hints:

To add more flavor to rice, try substituting water for a favorite meat or vegetable broth or stock. The ratio of broth/stock to rice will be the same as water to rice.

For approximate rice cooking times and suggested rice/water ratios, see "Rice & Water Measurement Table" on page 10.

7.

## DELAY TIMER

1. Using the provided rice measuring cup, add rice or grain to the inner pot.
2. Rinse for 10 seconds and drain the water. Repeat this process at least 2 times, or until the water runs clear.
3. For white or brown rice, fill with water to the line that matches the number of cups of rice being cooked. For other grains, see "Grain & Water Measurement Table" on page 11.
4. Place the inner pot into the cooker and close the lid securely.
5. Plug the power cord into an available 120V AC wall outlet.
6. Press (⏻) to turn the cooker on.
7. Press **Delay Timer**.
8. Press (+) or (-) to increase or decrease the delay time by one hour increments. It may be set to have grains ready in 1 to 15 hours for **White Rice** or **Oatmeal** and 2 to 15 hours for **Brown Rice** and **Multigrain**.
9. Once the desired time is selected, press the **White Rice**, **Brown Rice**, **Multigrain**, or **Oatmeal** button, depending on the type of grain being cooked.
10. The cooking indicator light will illuminate and the digital display will count down from the input delay time.
11. Once the delay time has elapsed, a chasing pattern will appear in the digital display signifying that the cooking cycle has begun.
12. The digital display will count down the final 10 minutes of cook time.
13. Once the cycle has completed, the cooker will beep and automatically switch to **Keep Warm**.
14. When finished, turn the cooker off by pressing (⏻) twice and unplug the power cord.  
.....

### Note:

- The delay timer includes cooking time. Once the delay timer elapses, rice or grains will be cooked and ready to serve.
- Food should not be left in the cooker on **Keep Warm** for more than 12 hours.
- Due to the longer cooking time needed, **Brown Rice** and **Multigrain** may only be delayed for 2 hours or more.

### Helpful Hints:

For approximate grain cooking times and suggested grain/water ratios, see "Grain & Water Measurement Table" on page 11.

The provided rice measuring cup is equivalent to a ¾ standard U.S. cup.



## OATMEAL

1. Using the provided rice measuring cup, add oatmeal to the inner pot.
2. For steel-cut oats, use a 1:2.5 water-to-oat ratio. For rolled oats, use a 1:2 water-to-oat ratio.
3. Place the inner pot into the cooker and close the lid securely.
4. Plug the power cord into an available 120V AC outlet.
5. Press (⏻) to turn the cooker on.
6. Press **Oatmeal**. The cooking indicator light will illuminate and the digital display will show a chasing pattern as the cooker begins heating.
7. Once the cycle has completed, the cooker will beep and automatically switch to **Keep Warm**.
8. When finished, turn the cooker off by pressing (⏻) twice and unplug the power cord.  
.....



### Caution:

The cooker will not switch to **Keep Warm** mode until all liquid has evaporated. Follow your recipe carefully and do not leave the cooker unattended.


Refer to the 'Grain & Water Measurement Table' on page 11 for cooking times, maximum quantities, and recommended water ratios.

# Rice & Water

## Measurement Table

Uncooked Rice*	Water: Using the Water Line (inside pot)	Water: Using the Rice Measuring Cup*	Approx. Cooked Rice Yield*	Cooking Times
2 Cups	<b>White Rice:</b> Line 2 <b>Brown Rice:</b> Line 2	<b>White Rice:</b> 2½ Cups <b>Brown Rice:</b> 2½ Cups	4 Cups	<b>White Rice:</b> 27-32 Min. <b>Brown Rice:</b> 36-41 Min.
3 Cups	<b>White Rice:</b> Line 3 <b>Brown Rice:</b> Line 3	<b>White Rice:</b> 3½ Cups <b>Brown Rice:</b> 3½ Cups	6 Cups	<b>White Rice:</b> 28-33 Min. <b>Brown Rice:</b> 39-45 Min.
4 Cups	<b>White Rice:</b> Line 4 <b>Brown Rice:</b> Line 4	<b>White Rice:</b> 4½ Cups <b>Brown Rice:</b> 4½ Cups	8 Cups	<b>White Rice:</b> 29-34 Min. <b>Brown Rice:</b> 42-48 Min.
5 Cups	<b>White Rice:</b> Line 5 <b>Brown Rice:</b> Line 5	<b>White Rice:</b> 5½ Cups <b>Brown Rice:</b> 5½ Cups	10 Cups	<b>White Rice:</b> 31-36 Min. <b>Brown Rice:</b> 45-51 Min.
6 Cups	<b>White Rice:</b> Line 6 <b>Brown Rice:</b> Line 6	<b>White Rice:</b> 6½ Cups <b>Brown Rice:</b> 6½ Cups	12 Cups	<b>White Rice:</b> 33-38 Min. <b>Brown Rice:</b> 48-54 Min.
7 Cups	<b>White Rice:</b> Line 7 <b>Brown Rice:</b> Line 7	<b>White Rice:</b> 7½ Cups <b>Brown Rice:</b> 7½ Cups	14 Cups	<b>White Rice:</b> 34-39 Min. <b>Brown Rice:</b> 51-57 Min.
8 Cups	<b>White Rice:</b> Line 8 <b>Brown Rice:</b> Line 8	<b>White Rice:</b> 8½ Cups <b>Brown Rice:</b> 8½ Cups	16 Cups	<b>White Rice:</b> 36-41 Min. <b>Brown Rice:</b> 54-60 Min.
9 Cups	<b>White Rice:</b> Line 9 <b>Brown Rice:</b> Line 9	<b>White Rice:</b> 9½ Cups <b>Brown Rice:</b> 9½ Cups	18 Cups	<b>White Rice:</b> 38-43 Min. <b>Brown Rice:</b> 57-63 Min.
10 Cups	<b>White Rice:</b> Line 10 <b>Brown Rice:</b> Line 10	<b>White Rice:</b> 10½ Cups <b>Brown Rice:</b> 10½ Cups	20 Cups	<b>White Rice:</b> 40-45 Min. <b>Brown Rice:</b> 60-66 Min.

\*Cups referenced are with the included rice measuring cup.  
(1 Rice Measuring Cup = ¾ U.S. Cup)



# Grain & Water

## Measurement Table

Grain	Uncooked Grain	Liquid	Approx. Cooked Grain Yield	Max. Uncooked Grain*	Function	Cooking Times
<b>Quinoa</b>	1 Part	1½ Parts	2½ Parts	8 Cups	White Rice	32-48 Min.
<b>Arborio</b>	1 Part	2 Parts	2 Parts	5 Cups	Steam/Risotto	12-17 Min.
<b>Barley</b>	1 Part	2 Parts	1 Part	2 Cups	Delay Timer & Multigrain	5 Hours
<b>Bulgur</b>	1 Part	2 Parts	2 Parts	5 Cups	Multigrain	35-50 Min.
<b>Couscous</b>	1 Part	1 Part	2 Parts	8 Cups	White Rice	29-60 Min.
<b>Steel Cut Oats</b>	1 Part	2½ Parts	2 Parts	4 Cups	Oatmeal	35-45 Min.
<b>Rolled Oats</b>	1 Part	2 Parts	2 Parts	3 Cups	Oatmeal	33-43 Min.

# Quick Rice

## Time Comparison Table

To use the **Quick Rice** function, begin by following steps 1 through 6 of "Rice & Grain" on page 7 then press **Quick Rice**. Refer to the "Rice & Water Measurement Table" for rice/water ratios and approximate cooked rice yields.

White Rice Uncooked Cups*	Cooking Time With Quick Rice Function	Approx. Time Savings Compared To White Rice Function
2 Cups	24-29 Min.	4-5 Min.
4 Cups	27-32 Min.	4-5 Min.
6 Cups	30-35 Min.	4-5 Min.
8 Cups	32-37 Min.	4-5 Min.
10 Cups	36-41 Min.	4-5 Min.

## Note:

- When cooking barley, you must use the **Delay Timer** for 4 hours in combination with the **Multigrain** function. The additional soaking time will ensure optimal flavor and texture.
- For best results when cooking barley or bulgur, let both grains sit on **Keep Warm** for 10 minutes before serving.
- If softer grains are desired, add an additional ½ cup of water or liquid.
- The **Quick Rice** function will only properly cook white rice. All other grains including brown rice should not be cooked using the **Quick Rice** function.

## Note:

- Maximum Quantity:** The maximum capacity of this unit is 10 cups of uncooked rice which yields 20 cups of cooked rice.
- Minimum Capacity:** do not attempt to cook less than 2 cups of uncooked white or brown rice.
- Cooking times are approximate. Altitude, humidity and outside temperature will affect cooking times.
- For best results, we recommend rinsing rice and grains in a bowl of water before cooking. Avoid using a strainer or colander, which may not be as effective in removing excess starch and may affect the final texture.

## STEAM

- Using the provided rice measuring cup, add 3 cups of water to the inner pot.
- Place the inner pot into the cooker.
- Place desired food into the provided steam tray, lower the tray into the cooker then close the lid securely.
- Plug the power cord into an available 120V AC outlet.
- Press (⏻) to turn the cooker on.
- Press **Steam**. The digital display will show a flashing "5" to represent five minutes of steam time.
- Press (+) or (-) to increase or decrease steaming time by one minute increments, up to 30 minutes. For suggested steaming times for meat and vegetables, see "Meat & Vegetable Steaming Table" on page 13.
- Once the time has been input, the cooker will beep and the digital display will stop flashing to indicate that the time has been successfully set.
- Once the water reaches a boil, the digital display will begin to count down from the input steam time.
- After the selected steam time has elapsed, the cooker will beep and automatically switch to **Keep Warm**.
- Using caution, check to see that the steamed food is cooked. If finished steaming, carefully remove the food to prevent overcooking. Wear a protective heat-resistant glove to prevent injury as the steam tray will be hot.
- When finished, turn the cooker off by pressing (⏻) twice and unplug the power cord.

## STEAM & COOK

- To steam foods while cooking grains, begin cooking grain by following steps 1 through 7 of "Rice & Grain" on page 7.
- Place the desired food into the provided steam tray. Open the lid using caution, lower the steam tray into the cooker then close the lid securely.
- Cook food according to "Meat & Vegetable Steaming Table" on page 13.

continued on the next page >>



### Caution:

Do not attempt to cook more than 6 cups of uncooked rice when steaming and cooking simultaneously.

Before placing the inner pot into the cooker, check that it is dry and free of debris. Adding the inner pot when wet may damage the cooker.

The rice cooker will not switch to **Keep Warm** mode until all liquid has evaporated. Follow your recipe carefully and do not leave the rice cooker unattended.

### Helpful Hints:

Parchment paper or aluminum foil may also be used while steaming. Place the paper/foil in the center of the steam tray and ensure it does not create a seal along the bottom of the tray.

For approximate grain cooking times and suggested grain/water ratios, see "Grain & Water Measurement Table" on page 11.

The provided rice measuring cup is equivalent to a ¾ standard U.S. cup.



## STEAM & COOK (CONT.)

- After the suggested amount of time has elapsed, open the lid to check steamed food for doneness. Use caution when opening the lid as hot steam will escape.
- If food is finished steaming, remove the steam tray. Wear a protective heat-resistant glove to prevent injury as the steam tray will be hot.
- Close the lid securely and allow the cooking cycle to continue.
- Once the cycle has completed, the cooker will beep and automatically switch to **Keep Warm**.
- When finished, turn the cooker off by pressing (⏻) twice and unplug the power cord.

### Meat & Vegetable Steaming Tables

Meat	Steaming Time	Safe Internal Temperature
Fish	25 Min.	140°F
Chicken	30 Min.	165°F
Pork	30 Min.	160°F
Beef	Medium = 25 Min. Medium-Well = 30 Min. Well = 33 Min.	160°F

Vegetable	Steaming Time
Asparagus	8-12 Minutes
Broccoli	10-15 Minutes
Cabbage	7-11 Minutes
Carrots	8-12 Minutes
Cauliflower	10-15 Minutes
Corn on the Cob	20-25 Minutes
Green Beans	9-13 Minutes
Peas	6-10 Minutes
Spinach	5 Minutes
Squash	8-12 Minutes
Zucchini	8-12 Minutes
Potatoes	25-30 Minutes

### Helpful Hints:

Since most vegetables only absorb a small amount of water, there is no need to increase the amount of water with a larger serving of vegetables.

To ensure meat tastes its best and to prevent food-borne illness, check that the meat is completely cooked prior to serving. If the meat is still uncooked, simply add more water to the inner pot and repeat the steaming process until the meat is adequately cooked.

We recommend beginning to steam your foods towards the end of the rice cooking cycle. This will allow steamed food and cooked grains to be ready around the same time.

### Note:

Altitude, humidity and outside temperature will affect cooking times.

These steaming charts are for reference only. Actual cooking times may vary.

Food should not be left in the rice cooker on **Keep Warm** for more than 12 hours.

When steaming, Aroma® recommends using 3 cups of water with the provided rice measuring cup.

## SOUP

1. Add desired ingredients to the inner pot.
2. Place the inner pot into the cooker and close the lid securely.
3. Plug the power cord into an available 120V AC wall outlet.
4. Press (⏻) to turn the cooker on.
5. Press **Soup**. The digital display will show a flashing "2" to represent 2 hours of cook time.
6. Press (+) or (-) to increase or decrease time by 1 hour increments, up to 8 hours.
7. The cooker will beep and the digital display will stop flashing to indicate that the time has been successfully set.
8. The cooker will now begin heating. The digital display will count down in one minute increments from the input cook time after it reaches a boil.
9. Using caution, open the lid after contents reach a boil and stir the ingredients with a long-handled wooden or heat-safe utensil if desired.
10. Once the time has elapsed, the cooker will beep and automatically switch to **Keep Warm**.
11. When finished, turn the cooker off by pressing (⏻) twice and unplug the power cord

## SAUTÉ-THEN-SIMMER®


1. Place the inner pot into the cooker.
2. Plug the power cord into an available 120V AC wall outlet.
3. Press (⏻) to turn the cooker on.
4. Press **Sauté-then-Simmer®**. The cooking indicator light will illuminate as the cooker begins to heat.
5. Add oil if desired for sautéing then close the lid securely and allow the inner pot to preheat for 2-4 minutes.
6. Once preheated, add in ingredients to sauté.

continued on the next page >>



### Caution:

Do not use the provided serving spatula to stir ingredients while using the **Sauté-Then-Simmer®, Risotto, Slow Cook, or Soup** functions. It is not intended to be used in contact with high temperatures. Instead, use a long-handled wooden or heat-safe utensil to stir while cooking.



## SAUTÉ-THEN-SIMMER® (CONT.)

7. When finished sautéing, stir in any other desired ingredients including liquid and close the lid securely.
8. The cooker will automatically reduce its heat and switch to simmer mode once liquids are added.
9. Once all liquid has been evaporated, the cooker will beep and automatically switch to **Keep Warm**.
10. When finished, turn the cooker off by pressing (⏻) twice and unplug the power cord.

## SLOW COOK

1. Add desired ingredients to the inner pot.
2. Place the inner pot into the cooker and close the lid securely.
3. Plug the power cord into an available 120V AC wall outlet.
4. Press (⏻) to turn the cooker on.
5. Press **Slow Cook**. The digital display will show a flashing "2" to represent 2 hours of slow cook time.
6. Press (-) or (+) to increase or decrease slow cook time by one hour increments, up to 10 hours.
7. Once the time has been input, the cooker will beep and the digital display will stop flashing to indicate that the time has been successfully set.
8. The cooker will now begin heating. The digital display will count down in one minute increments from the input slow cook time.
9. Using caution, open the lid occasionally and stir the ingredients with a long-handled wooden or heat-safe spoon if desired.
10. Once the time has elapsed, the cooker will beep and automatically switch to **Keep Warm**.
11. When finished, turn the cooker off by pressing (⏻) twice and unplug the power cord.

### Note:

- Slow cooking requires a small amount of liquid.
- Food should not be left in the rice cooker on **Keep Warm** for more than 12 hours.

## RISOTTO

1. Place the inner pot into the cooker.
2. Plug the power cord into an available 120V AC wall outlet.
3. Press (⏻) to turn the cooker on.
4. Press **Risotto**. The cooking indicator light will illuminate as the cooker begins to heat.
5. Add oil for sautéing then close the lid securely and allow the inner pot to preheat for 2–4 minutes.
6. Open the lid and add aromatics or other ingredients to sauté. Stir occasionally with a long-handled wooden utensil to sauté evenly.
7. Add in liquids and any remaining ingredients. Stir then close the lid and allow the cooker to simmer.
8. Once the cooking cycle is complete, the cooker will beep and automatically switch to **Keep Warm**.
9. When finished, turn the cooker off by pressing (⏻) twice and unplug the power cord.  
.....

## CAKE

1. Prepare one prepackaged cake mix according to the instructions or prepare your own cake batter.
2. Spray the interior of the inner pot with nonstick cooking spray.
3. Pour the cake mixture into the inner pot.
4. Place the inner pot into the cooker then close the lid securely.
5. Plug the power cord into an available 120V AC wall outlet.
6. Press (⏻) to turn the cooker on.
7. Press **Cake**. The cooking indicator light will illuminate as the cooker begins heating.
8. Once the cycle has completed, the cooker will beep and automatically switch to **Keep Warm**.
9. When finished, turn the cooker off by pressing (⏻) twice and unplug the power cord.  
.....

16.

### Note:

The **Risotto** function uses our patented **Sauté-then-Simmer®** technology that begins by applying high heat for sautéing then automatically switches to simmer mode once liquid is added.

### Note:

Cooking time cannot be adjusted for the **Cake** function.

Do not attempt to cook more than one package of cake mix (15.25 oz.) in this appliance at one time.

## EGGS

1. Using the provided rice measuring cup, add 3 rice measuring cups of water to the inner pot.
2. Place the inner pot into the cooker.
3. Place up to 9 large eggs in the provided steam tray.
4. Place the steam tray into the cooker and close the lid securely.
5. Plug the power cord into an available 120V AC wall outlet.
6. Press (⏻) to turn the cooker on.
7. Press **Eggs** and use the (+) or (-) buttons to adjust the cook time between 6 minutes (for soft boiled) and 14 minutes (for hard boiled).
8. Once the time is selected, the cooker will beep to indicate it is setting at the displayed time. The display will stop flashing to indicate it has set.
9. When the water reaches a boil, the digital display will count down in one minute increments from the selected time.
10. Once the selected time has passed, the cooker will beep and switch to **Keep Warm**.
11. Use caution when opening the lid as there will be escaping steam. Using a utensil, remove the eggs and place in a cold bath of water to prevent eggs from cooking further.
12. When finished removing eggs, turn the cooker off by pressing (⏻) twice and unplugging the power cord.  
.....

## REHEAT

1. Add desired food to the inner pot.
2. Place the inner pot into the cooker and close the lid securely.
3. Plug the power cord into an available 120V AC wall outlet.
4. Press (⏻) to turn the cooker on.
5. Press the **Reheat** button.
6. The cooker will beep and a chasing pattern will be in the display.
7. Once the reheating is complete, the cooker will automatically switch to **Keep Warm**.
8. When finished, turn the cooker off by pressing (⏻) twice and unplug the power cord.  
.....

### Note:

Food should not be left in the cooker on **Keep Warm** for more than 12 hours.

Opening the lid during the cooking cycle causes a loss of heat and steam. Cooking time may be prolonged if the lid is opened before the food is finished.

## Helpful Hints:

For best results when using the **Reheat** function, make sure food is stirred and not clumped. If food is dry, stir in a small amount of water.

17.





To Enhance and Enrich Lives.



[www.AromaCo.com](http://www.AromaCo.com)